

PARTS LIST
LOBE PUMP
BLK4-T

Keep this parts lists with Installation, Operation and Maintenance Instructions.

To order the required spare parts, indicate the desired Reference(s).

- ◆ Sets of parts or parts available to order.

BLK4-T



* 1, 2, 4... : Quantity in equipment - (1), (2), (4)... : Quantity in kit

Item	Available	Description	Qty*	Ref.	Maintenance kit	Wear part
2	◆	TRILOBE ROTOR	1	226836		
08D 105A	◆	SET OF 3 LIP SEALS CCL50-BLK4T LIP SEAL CCL50I-BLK4T	1 (3)	314074.00		●
13	◆	STANDARD SLEEVE + SHIMS KIT 32	1	317603.00		
13B	◆	SPECIAL SLEEVE FOR MOLASSES + SHIMS KIT 32	1	316773.00		
32	◆	SHIMS KIT	1	225446		
111 80 80B 80D	◆	WET END SEAL KIT (80+80A+80B+80D) SET OF SEALS SET OF SEALS SET OF SEALS	1 (2) (2) (2)	315141.00		
450	◆	CCL50-BLK4T OIL - CAN 3 L	1	315598.00		